



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87290A 4	HOUSING ASSEMBLY-Thermostat	1		
2	23	47511	SLEEVE	1		
3	22	32803	PLUG-Pipe (.375)	2		
4	22	98477A 2	VALVE ASSEMBLY	1		
5	10	98476	SCREW (#10-32 x 6.00)	1		
6	30	98475	BALL-Nylon	2		
7	24	75533	SPRING	2		
8	11	29488	NUT (#10-32)	1		
9		807252 1	THERMOSTAT (140 Degree)	1		
10	27	47510	GASKET-Thermostat	1		5
11	23	47508	SLEEVE-Thermostat	1		
12	27	41812 2	GASKET-Thermostat Cover	1		5
13		47441A 1	COVER-Thermostat	1		
14	10	14164	SCREW (.375-16 x 4.375)	2		
15	12	20553	WASHER	2		
16	27	53045 1	GASKET-Thermostat Housing	1		5
17	32	816197	HOSE-Pump to Cooler	1		
17	32	53461 19	HOSE (7.00 In.)-Pump to Transcool	1		
18	54	18076 6	CLAMP	8		
19	32	17435 65	HOSE-Sea Pump to Drive Unit (Plu	1		
20	32	12818	HOSE-Oil Cooler to Oil Cooler	1		3
21	22	13177	TUBE-Water Hose (NON POWER	1		
22	32	64346	HOSE-Oil Cooler to Thermostat Hou	1		
23	32	847677	HOSE-Thermostat Housing to Wate	1		
24	54	18076 8	CLAMP	2		
25	32	848955	HOSE-Thermostat Cover (PORT)	1		
26	32	848954	HOSE-Thermostat Cover (STARBO	1		
27	54	18076 4	CLAMP	8		
28	32	847764A 1	HOSE ASSEMBLY (22.00 In.) (SS	1		
28	32	847764A 2	HOSE ASSEMBLY (17.00 In.) (SS	1		
29	54	847752 18	CLAMP/HOSE END (Red)	4		
30		12552	LIFTING EYE	1		
-	27	99386A96	GASKET SET-Engine Overhaul	-		