



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		14750	TRANSMISSION ASSEMBLY	1	
2	22	47629	ELBOW	2	
3	22	88517	FITTING	1	
4		12128	LEVER-Shift	1	
5	16	63335	STUD	1	
6	12	39143	WASHER	1	
7	11	20361	NUT (.250-28)	2	
8	12	29245	WASHER	2	
9		47334A 2	BRACKET ASSEMBLY-Mounting (E	1	
10		35852	MOUNT	1	
11	10	47462	SCREW (.437-14 x 1.250)	2	
12	13	32993	LOCKWASHER (.437)	2	
13	10	47462	SCREW (.437-14 x 1.250)	2	
14	13	32993	LOCKWASHER (.437)	2	
15		48461	ADAPTOR-Dipstick Tube to Transr	1	
16	25	48462	O RING	1	
17		48463	TUBE-Dipstick	1	
18		48464	DIPSTICK	1	
19	25	35276	O RING	1	
20		48466	BRACKET-Dipstick Tube	1	
21	10	34290	SCREW (.250-20 x .625)	2	
22	13	26992	LOCKWASHER (.250)	2	
23	54	67015	CLAMP	1	
24	10	60300	SCREW (.250-28 x .750)	1	
25	12	29245	WASHER	2	
26	11	20361	NUT (.250-28)	1	
27		47340A 1	BRACKET ASSEMBLY-Mounting (F	1	
28		35852	MOUNT	1	
29	10	60179	SCREW (.437-14 x 3.500)	6	
30	13	32993	LOCKWASHER (.437)	6	
31	32	47516 6	HOSE ASSEMBLY (30.00 In.)	2	