



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A 7	HOUSING ASSEMBLY-Flywheel	1		
2		88791	MOUNT-Rubber-Flywheel Housin	2		
3	23	99322	SPACER-Rubber Mount-Flywheel	2		
4	10	37612	SCREW (.375-16 x 1.250)-Flywheel	3		
4	10	32132	SCREW (.375-16 x 1.750)-Flywheel	1		
5	16	64066	STUD (2.750 In.)-Flywheel Housing	2		
6	11	32219	NUT (.375-16)-Flywheel Housing At	2		
7	13	35048	LOCKWASHER (.375)-Flywheel Ho	8		
8	12	20572	WASHER-Special (.375)-Housing S	1		
9	54	78945	J CLIP-Flywheel Housing Stud	2		
10		818719A 3	COVER KIT-With Gasket	1		60
11	10	32773	SCREW (.250-20 x .875)-Cover to F	6		
12	84	62826A 6	CABLE ASSEMBLY (Black)	2		
13	54	62494	CLIP-Water Hose	1		
14	12	20553	WASHER	5		