



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		44187T	HOUSING-Flywheel	1		
2	19	12304	PLUG-Timing Window	1		
3	10	34353	SCREW (.375-16 x 1.00)	1		
3	10	37612	SCREW (.375-16 x 1.250)	1		
3	10	47688	SCREW (.375-16 x 2.750)	2		
4	13	35048	LOCKWASHER (.375)	7		
5	12	20553	WASHER	5		
5	12	20572	WASHER (FOR SLOT)	1		
6	54	78945	J CLIP	2		
7	16	64066	STUD (2.750 In.)	2		
8	11	32219	NUT (.375-16)	2		
9	84	62826A 7	CABLE ASSEMBLY (21.00 In.)-Groi	1		
9	84	62826A 6	CABLE ASSEMBLY (13.00 In.)-Groi	1		
10	54	62494	CLIP-Hose	1	FOR MC III & V TRANSMISSION	
11	19	38606	PLUG	1	FOR MC III & V TRANSMISSION	
12	11	35045	NUT (.250-28)	1	FOR MC III & V TRANSMISSION	
13	12	39143	WASHER	1	FOR MC III & V TRANSMISSION	
14	16	63335	STUD	1	FOR MC III & V TRANSMISSION	
15	12	21631	WASHER	2	FOR MC III & V TRANSMISSION	
16	23	31866	SPACER	1	FOR MC III & V TRANSMISSION	
17	11	20361	NUT (.250-28)	1	FOR MC III & V TRANSMISSION	
18		17917	BRACKET-Shift	1	FOR MC III & V TRANSMISSION	
19	10	28668	SCREW (.250-20 x .875)	2	FOR MC III & V TRANSMISSION	
20	13	26992	LOCKWASHER (.250)	2	FOR MC III & V TRANSMISSION	
21		93911A 4	HOUSING ASSEMBLY-Support	1	FOR BRAVO DRIVELINE MODEL	
22	22	74036	FITTING-Grease	2	FOR BRAVO DRIVELINE MODEL	
23	10	47651	SCREW (.437-14 x 1.500)	6	FOR BRAVO DRIVELINE MODEL	
24	13	32993	LOCKWASHER (.437)	6	FOR BRAVO DRIVELINE MODEL	