



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|----------|------------------------|-----|---------|----------|
| 1 | | 817119 1 | ALTERNATOR ASSEMBLY | 1 | (Blue) | |
| 2 | 11 | 42768 | NUT | 1 | | |
| 3 | 13 | 42769 | LOCKWASHER | 1 | | |
| 4 | | 42770 | PULLEY | 1 | | |
| 5 | 23 | 811865 | SPACER | 1 | | |
| 6 | | 811866 | FAN | 1 | | |
| 7 | 23 | 811867 | SPACER | 1 | | |
| 8 | | 811868 | BRACKET ASSEMBLY-Front | 1 | | |
| 9 | 10 | 811869 | SCREW | 3 | | |
| 10 | 30 | 811870 | BEARING-Ball | 1 | | |
| 11 | | 811871 | RETAINER | 1 | | |
| 12 | | 811872 | ROTOR ASSEMBLY | 1 | | |
| 13 | | 811873T | STATOR ASSEMBLY | 1 | | |
| 14 | | 811874T | BRACKET ASSEMBLY-Rear | 1 | | |
| 15 | | 811875T | RECTIFIER ASSEMBLY | 1 | | |
| 16 | 10 | 811876 | SCREW | 1 | | |
| 17 | | 811877 | HOLD | 2 | | |
| 18 | 11 | 811878 | NUT | 4 | | |
| 19 | | 811879 | CONDENSER ASSEMBLY | 1 | | |
| 20 | | 811880 | HOLD | 1 | | |
| 21 | 11 | 811881 | NUT | 1 | | |
| 22 | 10 | 42773 | THRU BOLT | 4 | | |
| 23 | | 811883T | REGULATOR ASSEMBLY | 1 | | |
| 24 | | 811884 | BRUSH | 2 | | |
| 25 | 24 | 811885 | SPRING-Brush | 2 | | |
| 26 | 10 | 811886 | SCREW-Set | 2 | | |
| 27 | | 811887 | TERMINAL | 1 | | |
| 28 | | 811888 | COVER | 1 | | |
| 29 | 10 | 811889 | SCREW-Set | 1 | | |
| 30 | 84 | 811890 | WIRE-Lead | 1 | | |
| 31 | 84 | 811891 | WIRE-Lead | 1 | | |
| 32 | 11 | 811878 | NUT | 4 | | |