



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		817119 1	ALTERNATOR ASSEMBLY	1	(Blue)	
2	11	42768	NUT	1		
3	13	42769	LOCKWASHER	1		
4		42770	PULLEY	1		
5	23	811865	SPACER	1		
6		811866	FAN	1		
7	23	811867	SPACER	1		
8		811868	BRACKET ASSEMBLY-Front	1		
9	10	811869	SCREW	3		
10	30	811870	BEARING-Ball	1		
11		811871	RETAINER	1		
12		811872	ROTOR ASSEMBLY	1		
13		811873T	STATOR ASSEMBLY	1		
14		811874T	BRACKET ASSEMBLY-Rear	1		
15		811875T	RECTIFIER ASSEMBLY	1		
16	10	811876	SCREW	1		
17		811877	HOLD	2		
18	11	811878	NUT	4		
19		811879	CONDENSER ASSEMBLY	1		
20		811880	HOLD	1		
21	11	811881	NUT	1		
22	10	42773	THRU BOLT	4		
23		811883T	REGULATOR ASSEMBLY	1		
24		811884	BRUSH	2		
25	24	811885	SPRING-Brush	2		
26	10	811886	SCREW-Set	2		
27		811887	TERMINAL	1		
28		811888	COVER	1		
29	10	811889	SCREW-Set	1		
30	84	811890	WIRE-Lead	1		
31	84	811891	WIRE-Lead	1		
32	11	811878	NUT	4		