



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		805185A36	DISTRIBUTOR ASSEMBLY	1		
2	10	90326	SCREW (#10-32 x .812)	4		
3		805759T 2	CAP ASSEMBLY	1		
4	27	805760	GASKET-Distributor Cap	1		2
5		13524T 1	WHEEL ASSEMBLY-Rotor Sensc	1		
6	87	861780A 2	SENSOR ASSEMBLY	1		
7	10	66686	SCREW	1	(#10-32 x 1.00)	
7	10	72202	SCREW	1	(#10-32 x 1.25)	
8	13	F8058	LOCKWASHER (#10 Internal)	2		
9	53	90916	RING-Retaining	1		
10	23	90915	BUSHING	2		
11	12	90931	WASHER-Thrust	1		
12	17	47617	PIN-Roll	1		
13	43	818807	GEAR-Drive	1		
14	27	34486 3	GASKET	1		2
15	12	856774	WASHER	1		
16	10	805559	SCREW (.375-16 x .875)	1		
17		52185	CLAMP	1		
18	37	92155	DECAL	1	(Distributor Firing Order)	
19	33	59571	SPARK PLUG	8		
20	84	847701A 7	CABLE SET-Ignition	1	(Blue) (Spark Plugs And Coil)	
21		32783	RETAINER (3 Wire)	2		
22		32784	RETAINER (4 Wire)	4		
23		54676	RETAINER (2 Wire)	2		
24	10	94247	SCREW (.375-16 x .750)	1		
25	12	856774	WASHER	1		
26	392	805570A 2	COIL KIT-Ignition	1		
27		65970T 1	BRACKET-Coil Mount	1	(On Electrical Bracket)	
28	10	41408	SCREW (#10-32 x 1.50)	1		
29	12	30164	WASHER	2		
30	13	26396	LOCKWASHER (#10)	3		
31	11	68219	NUT (#10-32)	3		
32	84	62826A13	CABLE ASSEMBLY-Ground	1	(Black - 19.00 Inches)	
33	12	30164	WASHER	4		
-	27	99386A96	GASKET SET	1	(Engine Overhaul)	