

## Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		849363 1	SENDER ASSEMBLY	1	(Oil Temperature) (Front Of Lower I	
2		48952	SENDER ASSEMBLY	1	(Water Temperature) (Intake Manil	
3		97257A 1	SENDER ASSEMBLY	1	(Water Temperature) (Thermostat I	
4	87	805605A 1	SWITCH ASSEMBLY	1	(Oil Pressure) (Back Of Lower Oil A	
5		815425T	SENDER ASSEMBLY	1	(Oil Pressure) (Lower Oil Adaptor)	
6		805544T	SENSOR ASSEMBLY	1	(Knock)	
7		816492A 6	ALARM KIT	1	(Audio Warning)	

