



- 23

VALVE KIT-RELIEF  
(UP PRESSURE)
- 24

VALVE KIT-RELIEF  
(DOWN PRESSURE)
- 25

VALVE KIT  
(THERMAL RELIEF)
- 26

REPAIR KIT  
(OVERHAUL)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14336A25	PUMP/MOTOR ASSEMBLY	1	(Design II - Etch Manufacturing Nu	1
2		891736T	MOTOR ASSEMBLY (Complete)	1	(Design II - Etch Manufacturing Nu	1
3		891737	BRUSH KIT	1		1
4		891738	HOLDER ASSEMBLY-Brushes	1		1
5	10	891739	SCREW-Brush Holder	2		1
6	25	891740	O RING	1		1
7		NSS	END CAP ASSEMBLY	1		
8	10	891741	SCREW	4		1
9		NSS	COVER ASSEMBLY	1	(With Bearing)	
10		NSS	FIELD AND FRAME ASSEMBL	1		
11		NSS	WASHER-Thrust	2		
12		NSS	ARMATURE	1		
13	10	823444	SCREW	2		
14		808728T	ADAPTER ASSEMBLY	1		
15		803852	COUPLING	1		
16	25	89498	O RING	1	(Motor End)	
17		18529	PUMP ASSEMBLY	1	(Includes Screws)	
18	35	89496	FILTER	2		
19	25	17645	O RING	1	(Reservoir End)	
20		883166A 2	RESERVOIR KIT	1	(With Filters-Ref 18 And O Ring-Rc	
21	36	861597	CAP-Oil Reservoir	1		
22	10	883167	SCREW (#8-32)	4		
23		812498A 1	VALVE KIT-Relief	1	(Up Pressure)	
24		812499A 1	VALVE KIT-Relief	1	(Down Pressure)	
25		95353A 1	VALVE KIT	1	(Thermal Relief)	
26		18545A 1	REPAIR KIT	1	(Overhaul)	