



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	849911T 1	HARNESS ASSEMBLY-EFI	1		
2	88	804638	FUSE-Mini	1	(Red - 10 AMP)	
3	88	804639	FUSE-Mini	2	(Blue - 15 AMP)	
4		807057T	RELAY	2	(Ignition And Fuel Pump)	
5	54	804352	CLIP-Hold Down	2	(Fuse Case)	