



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		805185A36	DISTRIBUTOR ASSEMBLY	1	
2	10	90326	SCREW (#10-32 x .812)	4	
3		805759T 2	CAP ASSEMBLY	1	
4	27	805760	GASKET-Distributor Cap	1	2
5		13524T 1	WHEEL ASSEMBLY-Rotor Sens	1	
6	87	861780A 2	SENSOR ASSEMBLY	1	
7	10	66686	SCREW (#10-32 x 1.00)	2	
8	13	26996	LOCKWASHER (#10)	2	
9	53	90916	RING-Retaining	1	
10	23	90915	BUSHING	2	
11	12	90931	WASHER-Thrust	1	
12	17	47617	PIN-Roll	1	
13	43	818807	GEAR-Drive	1	
14		52185	CLAMP	1	
15	12	856774	WASHER	1	
16	10	805559	SCREW (.375-16 x .875)	1	
17	27	34486 3	GASKET	1	2
18	37	92155	DECAL-Distributor Firing Order	1	
19	33	59571	SPARK PLUG	8	
20	84	847701A 7	CABLE SET-Ignition	1	(Spark Plugs And Coil) (Blue)
21		32783	RETAINER (3 Wire)	2	
22		32784	RETAINER (4 Wire)	4	
23		54676	RETAINER (2 Wire)	2	
24	10	94247	SCREW (.375-16 x .750)	1	
25	12	856774	WASHER	1	
26	392	805570A 2	COIL KIT-Ignition	1	
27		65970T 1	BRACKET-Coil Mount	1	(On Electrical Bracket)
28	10	41408	SCREW (#10-32 x 1.500)	1	
29	12	30164	WASHER	2	
30	13	26996	LOCKWASHER (#10)	2	
31	11	68219	NUT (#10-32)	2	
-	27	818572A98	GASKET SET-Engine Overhaul	1	