



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	808011A 1	STARTER ASSEMBLY	1	(TRANSMISSION & DRIVELINE I	27
2		850401	DRIVE HOUSING	1		27
3	89	850408	SOLENOID SWITCH	1		27
4		850409	PLUNGER KIT	1		27
5		850410	SHIFT LEVER KIT	1		27
6		850411	CENTER BEARING KIT	1		27
7		850402	DRIVE KIT	1		27
8		850403	ARMATURE KIT	1		27
9		850404	HOLDER KIT-Brush	1		27
10		850405	FIELD COIL	1		27
11		850406	CE FRAME KIT	1		27
12	10	850407	THRU BOLT	2		27
13		850412	SEALING PACKAGE KIT	1		27