



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	808011A 1	STARTER ASSEMBLY	1	(TRANSMISSION & DRIVELINE I	
2		850401	DRIVE HOUSING	1		
3	89	850408	SOLENOID SWITCH	1		
4		850409	PLUNGER KIT	1		
5		850410	SHIFT LEVER KIT	1		
6		850411	CENTER BEARING KIT	1		
7		850402	DRIVE KIT	1		
8		850403	ARMATURE KIT	1		
9		850404	HOLDER KIT-Brush	1		
10		850405	FIELD COIL	1		
11		850406	CE FRAME KIT	1		
12	10	850407	THRU BOLT	2		
13		850412	SEALING PACKAGE KIT	1		