



◀ THERMOSTAT HOUSING ▶

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87290A 4	HOUSING ASSEMBLY-Thermostat	1		
2	23	47511	SLEEVE	1		
3	22	32803	PLUG-Pipe (.375)	2		
4	22	98477A 2	VALVE ASSEMBLY	1		
5	10	98476	SCREW (#10-32 x 6.00)	1		
6	30	98475	BALL-Nylon	2		
7	24	75533	SPRING	2		
8	11	29488	NUT (#10-32)	1		
9		807252 1	THERMOSTAT (140 Degrees)	1		
10	27	47510	GASKET-Thermostat	1		12
11	23	47508	SLEEVE-Thermostat	1		
12	27	41812 2	GASKET-Thermostat Cover	1		12
13		47441A 1	COVER-Thermostat	1		
14	10	14164	SCREW (.375-16 x 4.375)	2		
15	12	20553	WASHER	2		
16	27	53045 1	GASKET-Thermostat Housing	1		12
17	32	848178	HOSE-Sea Water Pump To Cooler	1	(SER. # 0F745195 THRU 0L000;	
17	32	849604	HOSE-Sea Water Pump To Cooler	1	(SER. # 0L000768 THRU 0L001;	13
18	32	17435 65	HOSE (38.00 Inch)-Sea Pump To C	1	(PLUG-IN MODELS)	
18	32	13556A 1	HOSE KIT (10.00 Feet)	1	(DRIVELINE MODELS)	
19	54	18076 6	CLAMP	2		
19	54	18076 6	CLAMP	8	(PLUG-IN MODELS)	
20	32	848956	HOSE-Oil Cooler To Oil Cooler	1		
21	22	13177	TUBE-Water Hose	1	(NON POWER STEERING)	
22	32	64346	HOSE-Oil Cooler To Thermostat Ho	1		
23	32	89718 1	HOSE-Thermostat Housing To Wat	1		
24	54	18076 8	CLAMP	2		
25	32	848955	HOSE-Thermostat Cover	1	(PORT)	
26	32	848954	HOSE-Thermostat Cover	1	(STARBOARD)	
27	54	18076 4	CLAMP	4		
28	32	847764A 2	HOSE ASSEMBLY (17.00 Inches)	2		
29	54	847752 18	CLAMP/COVER-Hose	4		
30		12552	LIFTING EYE	1		
-	27	818572A97	GASKET SET-Engine Overhaul	1		9
-	27	818572A98	GASKET SET-Engine Overhaul	1		