



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A69	PUMP ASSEMBLY-Sea Water	1	(COMPLETE)	9
NS	22	36382	PLUG-Pipe (.250-18)	2		
2	46	72774A89	BODY/IMPELLER KIT-Sea Water	1		
3	27	805215 1	GASKET-Cover To Outer Wear	1		
4	27	94914	GASKET-Body To Wear Plate	2		
5	47	59362 1	IMPELLER	1		
6	25	94288	RING-Quad-Pump Housing	1		
7		87631A 4	COVER KIT-Sea Water Pump (	1		
8	10	74822	SCREW (.312-18 x 3.500)	5		
9	12	20084	WASHER	5		
10		94916	WEAR PLATE-Outer	1		
11		94576	WEAR PLATE-Inner	1		
12		818367A 1	HOUSING ASSEMBLY-Sea Water	1		
13	26	90562	SEAL-Oil-Sea Water Pump Sha	2		
14		818366A 1	SHAFT KIT-Sea Water Pump	1		
15		818745A 1	SLIP RING KIT	1		
16	12	89664	WASHER	1		
17	30	72961	BEARING-Ball-Sea Water Pump	2		
18	53	23720	RING-Retaining-Ball Bearing	1		
19	26	806930	SEAL-Oil-Sea Water Pump Sha	1		
20	10	79953A 2	SCREW ASSEMBLY-Plug	1		
21	25	805726	O RING	1		
22	12	20084	WASHER	1		
23	11	67980	NUT (.312-18)	1		
24		818365 1	PULLEY	1	(BLUE)	
25		818368T 1	BRACKET-Sea Water Pump	1		
26	10	90042	SCREW (.437-14 x 1.500)	2		
27	10	76926	SCREW (.375-16 x .875)	2		
28	13	35048	LOCKWASHER (.375)	2		
29	10	99204	SCREW (.437-14 x 1.00)	1		
30	43	818381 2	PINION STUD	1		
31		818380T	BUSHING	1		
32		818382	PULLEY	1		
33	11	817618	NUT (.437-20)	1		
34	57	69143T	V BELT	1		
35	12	27025	WASHER	1		
36		818379T	BRACKET-Idler	1		
37	12	45176	WASHER	2		