



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		16413A 9	THERMOSTAT HOUSING ASSEM	1		
2	22	32803	PIPE PLUG	1		
3	10	17989	SCREW IF APPLIC	1		
4	24	75533	SPRING IF APPLIC	2		
5	30	98475	NYLON BALL IF APPLICA	2		
6	11	29488	NUT IF APPLIC	1		
7	25	30224	O-RING	1		
8	27	53045 1	GASKET	1		
9		805273 1	THERMOSTAT (143DEGREES)	1		
10	23	17495 1	SLEEVE	1		
11	27	33179 2	GASKET	1		
12		17494A 1	COVER	1		
13	10	60410	SCREW (4-1/4")	2		
15	32	817433	HOSE (MOLDED)	2		
16	54	815504220	CLAMP	AR		
17	32	17435 70	HOSE, SEA PUMP TO DRIVE UNI	1		
18	32	805251	HOSE, OIL COOLER TO SEA PUM	1		
19	32	816286 1	HOSE, OIL COOLER TO THERMO	1		
20	32	89718 1	HOSE, THERMOSTAT HOUSING	1		
21	54	815504232	CLAMP	2		
22	32	89749 1	HOSE, THERMOSTAT COVER (P)	1		
23	32	89730 1	HOSE, THERMOSTAT COVER (S	1		
24	54	47715	CLIP	1		
25		12552	LIFTING EYE	1		