



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90747A	3 DISTRIBUTOR ASSEMBLY	1		
2		16457A	4 CAP	1		
3	10	90926	SCREW	4		
4	27	98242	1 GASKET	1		
5		13524A	5 ROTOR/SENSOR WHEEL	1		
11	87	91019A	3 SENSOR ASSEMBLY	1		
12	10	66686	SCREW (1")	1		
12	10	72202	SCREW (1-1/4")	1		
13	43	813776	1 DRIVE GEAR	1		
14	17	47617	PIN	1		
15	23	90915	BUSHING	2		
16	27	34486	3 GASKET	1		3
17		52185	CLAMP	1		
18	10	35169	SCREW	1		
19	13	26996	LOCKWASHER	2		
20	11	68219	NUT	2		
21	84	816608A61	SPARK PLUG WIRE KIT	1		
23	33	59571	SPARK PLUG	8		
24		54676	RETAINER (2 WIRE)	2		
25		32783	RETAINER (3 WIRE)	2		
26		32784	RETAINER (4 WIRE)	2		
27	392	7803A	4 IGNITION COIL	1		
28		77294T	BRACKET	1		
29	10	41408	SCREW (1-1/2")	1		
30	12	30164	WASHER	2		
31	13	26992	LOCKWASHER	2		
32	11	45076	NUT	2		
33	10	59645	SCREW (3/4")	2		
34	13	39107	LOCKWASHER	2		
35	12	20084	WASHER	2		
36	16	90096A	1 STUD ASSEMBLY	2		
37	54	72821	RETAINER	2		