

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		814624A	FUEL PUMP	1	
2	27	34213	GASKET	1	3
3	10	34354	SCREW (1-1/2")	2	
4	13	35048	LOCKWASHER	2	
5		35377	PUSH ROD	1	
6		89876A	BASE	1	
7	22	36382	PIPE PLUG	3	
8	10	26066	SCREW	2	
9	11	35814	NUT	2	
10	35	60494	FUEL FILTER	1	
11	22	33821	CONNECTOR	2	
12	32	814884T	FUEL LINE, FILTER TO PUMP	1	
13	32	814885T	FUEL LINE, FUEL PUMP TO CARB	1	
14	32	73815	HOSE, FUEL PUMP TO CARBURE	1	
15	22	93385	ELBOW	1	

