



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		807323A 5	BOX-ELECTRICAL COMPONENTS	1		
2		806762A 1	VELCRO KIT	1		
3		805443	MODULE ASSEMBLY-SPARK COI	1		
4	11	64015	NUT (1/4-20)	1		
5	89	96054T	SOLENOID ASSEMBLY-STARTEF	1		
6	13	26395	LOCKWASHER (#8)	2		
7	11	26419	NUT (#8-32)	2		
8	13	26392	LOCKWASHER (1/4)	2		
9	11	94330	NUT (1/4-20)	2		
10	12	35462	WASHER	2		
11	11	64015	NUT (1/4-20)	2		
12	85	97861	INSULATOR-STARTER SOLENOI	1		
13	88	11178	BREAKER-CIRCUIT (50 AMP)	1		
14	10	45862	SCREW (#10-32 X 7/8 IN.)	2		
15	11	61356	NUT (#10-32)	2		
16	13	26396	LOCKWASHER (#10)	2		
17	11	68219	NUT (#10-32)	2		
18		805615A 2	SCREW ASSEMBLY-THUMB	1		
19	10	24323	SCREW-SET	3		
20	12	35462	WASHER	3		
21	11	64015	NUT (1/4-20)	3		
22		860252R 2	MODULE-ECM	1	(454 MAG)	
22		860252R 2	MODULE-ECM	1	(454 MAG)	
22		860253R 1	MODULE-ECM	1	(502 MAG)	
23	10	76596	SCREW (1/4-20 X 1-1/4 IN.)	4		
24	12	20533	WASHER	4		
25	11	805562	NUT (#10-24)	3		
26		804642	FUSE (15 AMP)	1		
26		804641	FUSE (10 AMP)	1		
27		805439T 3	LID-ELECTRICAL BOX	1		
28		42600A 3	CONTROLLER-MERCATHODE	1		
29	12	56681	WASHER	2		
30	11	805562	NUT (#10-24)	2		
31	11	68219	NUT (#10-32)	4		
32	10	62568	SCREW	1		
33		807057T	RELAY-FUEL PUMP	1		
33		807057T	RELAY-IGNITION SYSTEM	1		