



9926

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806193A.33	MONITOR ASSEMBLY, Oil	1		
2	36	808625	CAP, Drive Lube Monitor, Oil Bott	1		
3	22	808624	CONNECTOR	1		
4	10	98261	SCREW, (.375-16 x .750)	2		
5		860065A.1	BRACKET KIT, Oil Bottle	1		
6		808023T	STRAP, Bracket	1		