



A = TO FUEL PRESSURE REGULATOR  
 B = TO FUEL PUMP

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		89876A 3	BASE ASSEMBLY	1		
2	22	816133 1	FITTING	1		
3	22	32561	PLUG-Pipe (1/4 in.)	1		
4	35	807172	FILTER-Fuel/Water Separator	1		
5	22	33821	FITTING	1		
6	22	808003	FITTING	1		
7	22	807958	FITTING-Inlet	1		
8		807956T	INSULATOR-Back	1		
9		807806T	INSULATOR-Cap	1		
10		807807T	INSULATOR-Base	1		
11		807918T	BRACKET	1		
12	11	45592	NUT (5/16-24)	2		
13	11	860069	NUT (3/8-16)	2		
14	32	807953T	FUEL LINE-Fuel Pump to Filter Base	1		
15	32	807954T	FUEL LINE-Fuel Regulator to Filter	1		