



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		48504A 2	ADAPTOR-Oil Filter	1		
2	10	34353	SCREW (.375-16 x 1.00)-Adaptor	2		
3	13	35048	LOCKWASHER (.375)-Adaptor Sc	2		
4	12	20553	WASHER-Oil Filter Adaptor Screw	2		
5		63880T	BRACKET-Oil Filter	1		
6	22	805632	CONNECTOR	1		
7	27	91892	GASKET-Adaptor Cover and Oil Fil	3		14
8	35	16595	FILTER-Oil	1		
9	10	47462	SCREW (.437-14 x 1.250)-Bracket	2		
9	10	37612	SCREW (.375-16 x 1.250)-Bracket	1		
10	13	35048	LOCKWASHER (.375)-Bracket Sc	1		
10	13	32993	LOCKWASHER (.437)-Bracket Sc	2		
11		90783A22	ADAPTOR ASSY-Oil Filter	1	(S/N: 0D456000 - 0D763745)	5
12	22	805632	CONNECTOR	1		
13		91830	COVER-Adaptor	1	(S/N: 0D456000 - 0D763745)	5
14	35	818400T	ADAPTOR	1	(S/N: 0D763746 - 0F348963)	4,6
15	10	91966	SCREW (.312-18 x 4.00)-Oil Filter A	1		
15	10	91967	SCREW (.312-18 x 3.500)-Oil Filter	1		
16	27	99893	GASKET-Oil Filter Adaptor	1		14
17		99889	VALVE-By Pass	1		
18	22	63825	ELBOW-Oil Hose	1		
19	22	48246	ELBOW-Oil Hose	1		
20	32	92357 38	HOSE-Oil-Adaptor (18.500 In.)	2	(S/N: 0D456000 - 0D456103)	5
20	32	92357 51	HOSE ASSY-Oil (26.00 In.)	1	(S/N: 0D456104 - 0F348963)	6
21	22	54035	ELBOW (90_)	1		
22	87	94009	SWITCH-Choke Pressure	1		
23	84	79139A16	CABLE ASSEMBLY (RED) (35.500	1		
24		816074	OIL COOLER	1	(BRAVO PLUG-IN MODELS)	
24		816482	OIL COOLER	1	(TRANSMISSION & DRIVELINE I	
NS		817043	COVER-End	2		
NS	27	817042	GASKET	2		
NS	25	814878	O RING	2		
NS	10	816767	SCREW	2		
25		816195 1	BRACKET-Oil Cooler	1	(BRAVO MODELS)	
26		816196 1	BRACKET-Oil Cooler	1	(BRAVO MODELS)	
27		12820	BRACKET-Oil Cooler	2		
28		56328A 1	BRACKET-Oil Cooler	2		
29	10	34353	SCREW (.375-16 x 1.00)	1		
30	13	35048	LOCKWASHER (.375)	1		
31	12	20553	WASHER	1		
32	10	48658	SCREW (.250-20 x .750)	6	(BRAVO MODELS)	