



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	46	72774A32	PUMP ASSEMBLY-Water	1	
2	46	72774A40	BODY ASSEMBLY-Water Pump	1	
3		87631A 4	COVER ASSEMBLY-Water Pump	1	
4	27	805215 1	GASKET-Cover to Outer Wear	1	
5	12	20084	WASHER-Cover Screw	5	
6	10	73275	SCREW (.312-18 x 2.875)	5	
7		94916	WEAR PLATE-Outer	1	
8	27	94914	GASKET-Body to Wear Plate	2	
9	19	59504	PLUG-Impeller	1	
10	47	59362 1	IMPELLER (USE WITHOUT KEY	1	
11	28	56662	KEY-Impeller Drive (Use where Ap	1	
12		94576	WEAR PLATE-Inner	1	
13	25	94288	QUAD RING-Pump Housing	1	
14	46	94913A 1	HOUSING ASSEMBLY-Water Pu	1	
15	26	90562	SEAL-Oil-Water Pump Shaft	2	
16	30	72961	BEARING-Ball-Water Pump Sh	2	
17		59501A 1	SHAFT-Water Pump	1	
18	53	23720	RING-Snap-Ball Bearing Retain	1	
19	26	72785	SEAL-Oil-Water Pump Shaft	1	
20		47530	HUB-Water Pump Pulley	1	
21		73798A 1	PULLEY-Water Pump	1	
22	10	47277	SCREW (.312-24 x .750)-Pulley	4	
23	13	39107	LOCKWASHER (.312)-Pulley Screw	4	
24	22	32802	PLUG-Pipe (FOR WATER PUMP B	1	4
25	57	74271T	V BELT-Water Pump	1	
26		47489A2	BRACKET KIT-Water Pump	1	
27	10	34354	SCREW (.375-16 x 1.500)-Water	1	
28	13	35048	LOCKWASHER (.375)	1	
29	13	32993	LOCKWASHER (.437)-Bracket Scr	1	
30	12	27025	WASHER-Bracket Screw	1	
31	10	47462	SCREW (.437-14 x 1.00)-Water Pui	1	
32	10	48948	SCREW (.437-14 x .875)-Water Pui	1	
33	12	29330	WASHER (FOR SLOT)	1	
34		64177	BRACE-Water Pump	1	
35	10	47462	SCREW (.437-14 x 1.250)-Brace to	1	
36	13	32993	LOCKWASHER (.437)-Brace Screw	1	
37	10	35786	SCREW (.375-24 x 1.00)-Water Pui	1	
38	13	35048	LOCKWASHER (.375)-Brace Screw	1	
39	11	46335	NUT (.375-24)-Brace Screw	1	