



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	46	72774A82	PUMP ASSEMBLY-Water (Comple	1	
2	46	72774A40	BODY ASSEMBLY-Water Pump	1	
3		821707 1	COVER-Water Pump	1	
4	10	39001	SCREW (.312-18 x 4.500)	5	
5	12	20084	WASHER	10	
6	27	805215 1	GASKET-Cover to Outer Wear Pl.	1	
7		94916	WEAR PLATE-Outer	1	
8	27	94914	GASKET-Body to Wear Plate	2	
9	19	59504	PLUG-Impeller	1	
10	47	59362 1	IMPELLER	1	
11		94576	WEAR PLATE-Inner	1	
12	25	94288	QUAD RING-Pump Housing	1	
13		818367A 1	HOUSING ASSEMBLY-Water Pu	1	
14	26	90562	SEAL-Oil-Water Pump Shaft	2	
15		818366A 1	SHAFT ASSEMBLY	1	
16		818745A 1	RING KIT-Slip	1	
17	30	72961	BEARING-Ball-Water Pump Sh	2	
18	53	23720	RING-Retaining-Ball Bearing	1	
19	26	821104	SEAL-Oil-Water Pump Shaft	1	4
20		818365T	PULLEY (BLACK)	1	
20		818365 2	PULLEY (BLUE)	1	
21	13	39107	LOCKWASHER (.312)	1	
22	11	21908	NUT (.312-18)	1	
23	10	28634A 1	SCREW PLUG ASSEMBLY	1	4
24	25	805726	O RING	1	
25		823185A2	BRACKET KIT-Water Pump Mount	1	
26	10	91903	SCREW (.437-14 x 1.750)	3	
27	10	98261	SCREW (.375-16 x .750)	2	
28	13	35048	LOCKWASHER (.375)	2	
29	10	47461	SCREW (.437-14 x 1.00)	1	
30	43	818381 1	PINION STUD	1	
31		818380	BUSHING	1	
32		818382	PULLEY	1	
33	11	817618	NUT	1	
34	57	69143T	V BELT	1	
35	12	27025	WASHER	1	
36	13	32993	LOCKWASHER (.437)	1	
37		818379T	BRACKET-Idler	1	
38	13	32993	LOCKWASHER (.437)	3	