



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|---------|----------------------------------|-----|---------------------------|----------|
| - | 50 | 17251A3 | STARTER ASSEMBLY | 1 | (TRANSMISSION & DRIVELINE | 4 |
| 1 | | 79206 | HOUSING ASSEMBLY | 1 | | |
| 2 | 23 | 33369 | BUSHING-Drive End Housing | 1 | | |
| 3 | | 814474 | COLLAR-- st | 1 | | |
| 4 | 53 | 33290 | RING-Retaining-Pinion Stop Colla | 1 | | |
| 5 | | 33291 | COLLAR-Pinion Stop | 1 | | |
| 6 | | 68608 | DRIVE ASSEMBLY-Clutch | 1 | | |
| 7 | | 79396 | PLATE-Bearing | 1 | | |
| 8 | 23 | 71694 | BUSHING-Bearing Plate | 1 | | |
| 9 | 12 | 68614 | WASHER-Bearing Plate | 1 | | |
| 10 | 10 | 79209 | SCREW-Bearing | 2 | | |
| 11 | | 68606 | ARMATURE | 1 | | |
| 12 | | NSS | SHOE-Pole-Field Coil (Delco Rem | 4 | | 1 |
| 13 | | NSS | SCREW (Delco Remy #1968396) | 4 | | 1 |
| 14 | | NSS | GROMMET-Field Coil (Delco Rem | 1 | | 1 |
| 15 | | NSS | FIELD COIL ASSY (Delco Remy # | 1 | | 1 |
| 16 | | NSS | WASHER-Leather (Delco Remy # | 1 | | 1 |
| 17 | | 79211 | FRAME-Commutator End | 1 | | |
| 18 | | NSS | BOLT-- (Delco Remy #1939970) | 1 | | 1 |
| 19 | | 33284 | HOLDER-Insulated-Field Frame B | 2 | | |
| 20 | | 33283 | HOLDER-Field Frame Brush Grou | 2 | | |
| 21 | | 33270 | BRUSH-Field Frame | 4 | | |
| 22 | | NSS | SCREW-Brush Lead (Delco Remy | 2 | | 1 |
| 22 | | NSS | SCREW-Brush Lead (Delco Remy | 2 | | 1 |
| 23 | | 33294 | SUPPORT | 2 | | |
| 24 | 24 | 33285 | SPRING-Field Frame Brush | 4 | | |
| 25 | | NSS | PIN-Dowel (Delco Remy #19856) | 1 | | 1 |
| 26 | | 33297 | LEVER-Shift | 1 | | |
| 27 | | NSS | STUD-Shift Lever (Delco Remy # | 1 | | 1 |
| 28 | 12 | 68615 | WASHER-Shift Lever Stud | 1 | | |
| 29 | 11 | 26484 | NUT (.312-18)-Shift Lever Stud | 1 | | |
| 30 | | 33317 | PLUNGER | 1 | | |
| 31 | 17 | 79207 | PIN-Plunger to Shift Lever | 1 | | |
| 32 | 24 | 46889 | SPRING-Plunger Return | 1 | | |
| 33 | | NSS | SCREW-Solenoid (Delco Remy # | 2 | | 1 |
| 34 | 89 | 18080 | SOLENOID | 1 | | |