



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A82	PUMP ASSEMBLY-Water (Comple	1		
NS	22	36382	PLUG-Pipe (.250-18)	2		
2	46	72774A89	BODY/IMPELLER KIT-Sea Wate	1		
3	27	805215 1	GASKET-Cover to Outer Wear	1		
4	27	94914	GASKET-Body to Wear Plate	2		
5	47	59362 1	IMPELLER	1		
6	25	94288	RING-Quad-Pump Housing	1		
7		821707 1	COVER-Sea Water Pump	1		
8	10	39001	SCREW (.312-18 x 4.500)	5		
9	12	20084	WASHER	10		
10		94916	WEAR PLATE-Outer	1		
11		94576	WEAR PLATE-Inner	1		
12		818367A 1	HOUSING ASSEMBLY-Sea Wate	1		
13	26	90562	SEAL-Oil-Sea Water Pump Sha	2		
14		818366A 1	SHAFT ASSEMBLY	1		
15		818745A 1	SLIP RING KIT	1		
16	30	72961	BEARING-Ball-Sea Water Pump	2		
17	53	23720	RING-Retaining-Ball Bearing	1		
18	26	806930	SEAL-Oil-Sea Water Pump Sha	1		
19		818365 2	PULLEY (BLUE)	1		1
20	10	28634A 1	SCREW ASSEMBLY-Drain	1	(EARLY DESIGN)	1
20	10	79953A 2	SCREW KIT-Drain	1	(LATE DESIGN)	
21	25	805726	O RING	1	(EARLY DESIGN)	
21	12	19183	WASHER	1	(LATE DESIGN)	
22	13	39107	LOCKWASHER (.312)	1		
23	11	21908	NUT (.312-18)	1		
24		823185A 2	BRACKET KIT-Sea Water Pump	1		
25	10	66024	SCREW (.437-14 x 1.750)	3		
26	10	28782	SCREW (.375-16 x .875)	2		
27	13	26993	LOCKWASHER (.375)	2		
28	10	99204	SCREW (.437-14 x 1.00)	1		
29	43	818381 1	PINION/STUD	1		1
30		818380	BUSHING	1		1
31		818382	PULLEY	1		
32	11	817618	NUT (.437-20)	1		
33	57	69143T	V BELT	1		
34	12	27025	WASHER	1		
35		818379T	BRACKET-Idler	1		
36	12	45176	WASHER	3		