



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	84	847722A	2 HARNESS ASSEMBLY-Wiring	1	
2		26079A	2 PLATE KIT	1	
3	10	15001	SCREW (#8-16 x .875)	4	
4		848131	1 BRACKET-Electrical Components	1	
5	88	11178	BREAKER-Circuit (50 AMP)	1	
6	13	26996	LOCKWASHER (#10)	2	
7	11	68219	NUT (#10-32)	2	
8	10	45862	SCREW (#10-32 x .875)	2	
9	11	61356	NUT (#10-32)	2	
10	89	818999A	2 SOLENOID ASSEMBLY-Starter	1	
11	25	818967	GROMMET	2	
12	23	818968	BUSHING	2	
13	12	29245	WASHER	2	
14	13	26992	LOCKWASHER (.250)	2	
15	10	76630	SCREW (.250-20 x 1.00)	2	
16	13	26995	LOCKWASHER (#8)	2	
17	11	26419	NUT (#8-32)	2	
18	13	26992	LOCKWASHER (.250)	2	
19	11	94330	NUT (.250-20)	2	
20		13611	SENDER ASSEMBLY-Oil Temperal	1	
21	13	26996	LOCKWASHER (#10)	3	
22	11	45076	NUT (#10-32)	3	
23	22	64013	REDUCER-Engine Block	2	
24		97257A	1 SENDER ASSEMBLY-Water Temp	1	Thermostat Housing
24		49734A	1 SENDER ASSEMBLY-Water Temp	OPT	1,5
25	10	88829	SCREW (#10-24 x .500)	4	
26		848191	1 BRACKET-Wire Harness	1	
27		815425	1 SENDER ASSEMBLY-Oil Pressure	1	
27		37293	1 SENDER ASSEMBLY-Oil Pressure	OPT	5
28	22	29085	FITTING (45 Degree)	1	
29		42600A	3 CONTROLLER ASSEMBLY	1	
30	12	30164	WASHER	2	
31	13	26996	LOCKWASHER (#10)	7	
32	10	41771	SCREW (#10-24 x .875)	2	
32	10	35401	SCREW (#10 x 1.00)	2	(DRIVELINE MODELS)
33	10	62568	SCREW (#10-16 x .375)	1	
34	11	68219	NUT (#10-32)	4	
35	84	86322A17	1 CABLE ASSEMBLY (Black)	1	(NON DRIVELINE MODELS)
36		814295A	1 IGNITION MODULE ASSEMBLY	1	
37	12	29245	WASHER	2	
38	11	66374	2 NUT (.250-20)	2	