



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90747A27	DISTRIBUTOR ASSEMBLY	1		
2		805759A 2	CAP ASSEMBLY	1		
3	27	805760	GASKET-Distributor Cap	1		2
4	10	90926	SCREW (#10-32 x .812)	4		
5		13524A 1	WHEEL ASSEMBLY-Rotor Sensc	1		
6	87	91019A 3	SENSOR ASSEMBLY	1		
7	10	66686	SCREW (#10-32 x 1.00)	1		
7	10	72202	SCREW (#10-32 x 1.250)	1		
8	43	818807	GEAR-Drive	1		
9	17	47617	PIN	1		
10	23	90915	BUSHING	2		
11	13	26996	LOCKWASHER (#10)	3		
12	11	68219	NUT (#10-32)	1		
13	84	86322A17	CABLE ASSEMBLY-Ground (Blac	1		
14	12	90931	WASHER-Thrust	1		
15	53	90916	RING-Retaining	1		
16	13	35048	LOCKWASHER (.375)	2		
17	12	20553	WASHER	1		
18	84	847701A 7	CABLE KIT-Ignition (Blue)	1	(Spark Plugs And Coil)	
19	33	813421	SPARK PLUG	8		
20		54676	RETAINER (2 Wire)	2		
21		32783	RETAINER (3 Wire)	2		
22		32784	RETAINER (4 Wire)	4		
23	37	92155	DECAL-Distributor (Firing Order)	1		
24	392	805570A 2	COIL KIT-Ignition	1		
25		65970T 1	BRACKET-Coil Mount	1	(On Electrical Bracket)	
26	10	41408	SCREW (#10-32 x 1.500)	1		
27	12	30164	WASHER	2		
28	13	26996	LOCKWASHER (#10)	2		
29	11	68219	NUT (#10-32)	2		
30	10	76926	SCREW (.375-16 x .875)	2		
31	27	34486 3	GASKET	1		2
32		52185	CLAMP	1		
33	13	26996	LOCKWASHER (#10)	2		
34	11	68219	NUT (#10-32)	2		
-	27	827014A97	GASKET SET-Engine Overhaul	1		