



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		48952	SWITCH ASSEMBLY-Water Temp	1	(Intake Manifold)	
2	13	26396	LOCKWASHER (#10)	1		
3	11	45076	NUT (#10-32)	1		
4	87	805605A	SWITCH ASSEMBLY-Engine Block	1		
5	11	68219	NUT (#10-32)	1		
6	13	26396	LOCKWASHER (#10)	1		
7		86047A	HOUSING KIT-Buzzer	1	(With Two Ring Connectors)	
8		86045	TIMER-Temperature Buzzer	1		
9		68878A	HORN ASSEMBLY	1		
10	10	69013	SCREW (#10-16 x .875)	2		
11	84	86044A	CABLE ASSEMBLY (20.00 Feet)	1	(Tan/Blue - Two Rings)	
7		86047A	HOUSING KIT-Buzzer	1	(With One Ring - One Spade Conn)	
8		86045	TIMER-Temperature Buzzer	1		
9		68878A	HORN ASSEMBLY	1		
11	84	86044A	CABLE ASSEMBLY (20.00 Feet)	1	(Tan/Blue - One Ring/One Spade)	
12	84	86044A	CABLE ASSEMBLY (36.00 Inches)	1		
12	84	88032A	CABLE ASSEMBLY (Tan/Blue)	1	(Harness To Sender)	
13	23	848552	BUSHING-Reducer	1	(Intake Manifold)	
14	22	64013	BUSHING-Reducer	1	(Engine Block)	