



Parts List					
Ref	Class	Part	Description	Qty	Footnote
12	22	805632	CONNECTOR	1	
13		91830	COVER-Adaptor	1	(S/N: 0D456000 - 0D763745) 5
14	35	818400T	ADAPTOR	1	(S/N: 0D763746 - 0F348963) 4,6
15	10	91966	SCREW (.312-18 x 4.00)-Oil Filter A	1	
15	10	91967	SCREW (.312-18 x 3.500)-Oil Filter.	1	
16	27	99893	GASKET-Oil Filter Adaptor	1	14
17		99889	VALVE-By Pass	1	
18	22	63825	ELBOW-Oil Hose	1	
19	22	48246	ELBOW-Oil Hose	1	
20	32	92357 38	HOSE-Oil-Adaptor (18.500 In.)	2	(S/N: 0D456000 - 0D456103) 5
20	32	92357 51	HOSE ASSY-Oil (26.00 In.)	1	(S/N: 0D456104 - 0F348963) 6
21	22	54035	ELBOW (90_)	1	
22	87	94009	SWITCH-Choke Pressure	1	
23	84	79139A16	CABLE ASSEMBLY (RED) (35.500	1	
24		816074	OIL COOLER	1	(BRAVO PLUG-IN MODELS)
24		816482	OIL COOLER	1	(TRANSMISSION & DRIVELINE I
NS		817043	COVER-End	2	
NS	27	817042	GASKET	2	
NS	25	814878	O RING	2	
NS	10	816767	SCREW	2	
25		816195	BRACKET-Oil Cooler	1	(BRAVO MODELS)
26		816196	BRACKET-Oil Cooler	1	(BRAVO MODELS)
27		12820	BRACKET-Oil Cooler	2	
28		56328A	BRACKET-Oil Cooler	2	
29	10	34353	SCREW (.375-16 x 1.00)	1	
30	13	35048	LOCKWASHER (.375)	1	
31	12	20553	WASHER	1	
32	10	49668	SCREW (.250-20 x .750)	6	(BRAVO MODELS)
32	10	60300	SCREW (.250-28 x .750)	4	
33	13	26992	LOCKWASHER (.250)	6	(BRAVO MODELS)
34	54	15095	J CLAMP	1	
35	22	63825	ELBOW (90_)	2	
36	32	92357 53	HOSE ASSEMBLY-Oil (28.00 In.)	1	
37	11	30506	NUT (.250-28)	4	
38	22	821914	FITTING-Filter Adaptor	1	(S/N: 0D763746 - 0F348963) 6
39	12	55822	WASHER	1	(S/N: 0D763746 - 0F348963) 6
40	25	90196	O RING-Filter	1	(S/N: 0D763746 - 0F348963) 6
41	32	92357 49	HOSE ASSY-Oil (24.00 In.)	1	(S/N: 0D456104 - 0F348963) 6
-	27	817118A90	Gasket Set	-	
-	27	827014A92	Gasket Set	-	