



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42600A 3	CONTROLLER	1,1		
2	11	68219	NUT	4,4		
3		18893T	BRACKET	1,1		
4	10	40001 16	SCREW, CONTOLLER	2,2		
5	11	40020 1	NUT, CONTROLLER SCREW	2,2		
6	10	62568	SCREW, CONTROLLER GROUND	1,1		
7	12	30164	WASHER, GROUND SCREW	2,2		
8	84	95084A 13	WIRE ASSEMBLY, FUSE (LONG-F	1,1		
9	88	79091	FUSE (20 AMP)	1,1		
10	84	95084A 2	WIRE ASSEMBLY, FUSE (SHORT	1,1		