



| Parts List | | | | | | |
|------------|-------|-----------|------------------------|-------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 814874 | SEAWATER PUMP ASSEMBLY | 1,1 | | |
| 02 | 10 | 801332604 | SCREW | 1,1 | | |
| 3 | 17 | 801332620 | PIN | 1,1 | | |
| 4 | 30 | 801332597 | BALL BEARING | 2,2 | | |
| 5 | 23 | 801332596 | SPACER | 1,1 | | |
| 6 | 53 | 801332595 | SNAP RING | 1,1 | | |
| 7 | 45 | 801332593 | SHAFT | 1,1 | | |
| 8 | 12 | 801332601 | THRUST WASHER | 1,1 | | |
| 9 | 26 | 801332600 | OIL SEAL | 2,2 | | |
| 10 | | 801332599 | SPREADER | 1,1 | | |
| 11 | 25 | 801332598 | O-RING | 1,1 | | |
| 12 | | 814873 | CAM | 1,1 | | |
| 13 | 47 | 801332602 | IMPELLER | 1,1 | | |
| 14 | 27 | 801332606 | GASKET | 1,1 | | |
| 15 | | 801332607 | COVER | 1,1 | | |
| 16 | 10 | 801332608 | SCREW | 6,6 | | |
| 17 | 25 | 801333850 | O-RING | 1,1 | | |
| 18 | 11 | 809922800 | NUT | 4,4 | | |
| 19 | 32 | 805375 | SEAWATER HOSE | 1,1 | | |
| 21 | 32 | 805376 | SEAWATER HOSE | 1,1 | | |
| 23 | 54 | 801326639 | CLAMP | 10,10 | | |
| 24 | 54 | 801761122 | CLAMP | 2,2 | | |
| 25 | 10 | 809915039 | SCREW | 1,1 | | |
| 27 | 12 | 809931067 | WASHER | 2,2 | | |
| 28 | 54 | 801331113 | CLAMP | 2,2 | | |
| 29 | 10 | 809913624 | SCREW | 2,2 | | |
| 30 | 11 | 40021 | NUT | 3 | | |
| 31 | | 801761589 | SUPPORT ANGLE | 2,2 | | |
| 32 | 10 | 809913483 | SCREW | 2,2 | | |
| 33 | 23 | 801763599 | SPACER | 2,2 | | |
| 34 | | 801763335 | DRAIN COCK | 1,1 | | |
| 35 | 32 | 801763997 | HOSE | 1,1 | | |
| 36 | | 801761588 | PLATE | 1,1 | | |
| 37 | 10 | 809913815 | SCREW | 1,1 | | |
| 38 | 32 | 801761585 | SEAWATER PIPE | 1, | | |
| 39 | 32 | 801761584 | HOSE | 1,1 | | |
| 40 | | 801763719 | SEAWATER PIPE | 1, | | |
| 40 | 32 | 801761586 | SEAWATER PIPE | 1, | | |
| 41 | 32 | 801763230 | HOSE | 1,1 | | |
| 42 | | 801763722 | SEAWATER PIPE | 1, | | |
| 42 | 32 | 801763228 | SEAWATER PIPE | 1, | | |