



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		18900A 1	TRANSMISSION ASSEMBLY (1.5)	1,1		
-		18901A 1	TRANSMISSION ASSEMBLY (2.0)	1,1		
-		18902A 1	TRANSMISSION ASSEMBLY (2.5)	1,1		
1		813278	HOUSING	1,1		
2		813279	COVER	1,1		
3		813280	VENT CAP	1,1		
4	13	813281	LOCKWASHER	12,12		
5	10	813282	SCREW	5,5		
6	10	813283	SCREW	1,1		
7	10	813284	SCREW	4,4		
8	10	813285	SCREW	2,2		
9	26	813286	OIL SEAL	1,1		
10	10	813287	SCREW	4,4		
11	11	813288	RETAINING PLATE	1,1		
12	32	813289	HOSE	1,1		
13		813290	BAFFLE PLATE	1,1		
14	17	813291	DOWEL PIN	2,2		
15	26	813292	OIL SEAL	1,1		
16	13	813293	LOCKWASHER	7,7		
17	10	813294	SCREW	7,7		
18		813295	CONTROL BLOCK	1,1		
19	10	813296	SCREW	1,1		
20	12	813297	WASHER	1,1		
21		813298	SHIFT LEVER	1,1		
22	11	813299	NUT	1,1		
23	87	813300	NEUTRAL SAFETY SWITCH	1,1		
24	27	813301	GASKET	1,1		
25	22	813302	PLUG	1,1		
26	12	813303	WASHER	1,1		
27	35	813304	COVER KIT	1,1		
28	35	815419	FLUID FILTER KIT	1,1		
29	25	813407	O-RING	1,1		
30	25	813406	O-RING	1,1		
31		813305	DIPSTICK	1,1		