



INTAKE MANIFOLD AND FRONT COVER

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12376	INTAKE MANIFOLD	1		
2	10	64900	BOLT, INTAKE MANIFOLD	12		
2	10	35787	BOLT, INTAKE MANIFOLD	8		
3	12	45175	WASHER, INTAKE MANIFOLD SC	20		
4	54	64628 1	LIFTING EYE	2		
5	27	98086A 1	GASKET SET, INTAKE MANIFOLD	1		2
6		54637	ADAPTOR PLATE (SIDE)	2		
7		54636	ADAPTOR PLATE (REAR)	1		
8		54635	ADAPTOR PLATE (FRONT)	1		
9	22	66201	CONNECTOR, INTAKE PUMP/IN	2		
10	32	66206	HOSE, BY-PASS - WATER PUMP,	1		
11	54	18076 3	CLAMP, BY-PASS HOSE	2		
12		17670	WATER PUMP	1		
13	27	49110	GASKET, WATER PUMP MOUN	2		2
14	10	32132	SCREW, WATER PUMP TO CYL	4		
15	13	35048	LOCKWASHER, WATER PUMP S	4		
16		13728 1	PULLEY, WATER PUMP	1		
17	10	47277	SCREW, PULLEY TO WATER PU	4		
18	13	39107	LOCKWASHER, WATER PUMP T	4		
19		72605 1	BALANCER, HARMONIC - CRANK	1		
20		41450	PULLEY, HARMONIC BALANCER	1		
21		814441	BALANCER BOLT KIT	1		
24	10	94207	BOLT, PULLEY	3		
25	12	47393	WASHER, PULLEY BOLT	3		
26	57	14458	BELT, ALTERNATOR DRIVE	1		
27		66215	COVER, CRANKCASE	1		
28	26	49154	OIL SEAL, CRANKCASE COVER	1		2
29	27	54529	GASKET, CRANKCASE COVER	1		2
30	10	28635	SCREW, CRANKCASE COVER TC	10		
31	13	26992	LOCKWASHER, COVER SCREW	10		
32		59966	POINTER, TIMING	1		