



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		98337A 2	OIL PUMP	1		
2	16	49108	STUD, OIL PUMP TO CYLINDER	1		
3		49149	SHAFT, OIL PUMP TO DISTRIBUTOR	1		
4		49198	BAFFLE, OIL PAN	1		
5	16	49144	STUD, BAFFLE	4		
6	12	25909	WASHER, OIL PAN BAFFLE/OIL PUMP	5		
7	11	37500	NUT, OIL PAN BAFFLE/OIL PUMP	5		
8		47552A 5	OIL PAN	1		
9	27	52550	GASKET SET, OIL PAN	1		2
10	22	32803	PLUG, PIPE	1		
11	10	55714	SCREW, OIL PAN (5/16-18 X 7/8")	10		
12	12	20546	WASHER, OIL PAN SCREW	10		
13	10	55715	SCREW, OIL PAN (1/4-20 X 7/8")	2		
14	12	20028	WASHER, OIL PAN SCREW	2		
15		86890A 2	TUBE, OIL LEVEL GAUGE	1		
16	11	47626	NUT, OIL LEVEL GAUGE TUBE	1		
17	22	78039	COUPLING, OIL LEVEL GAUGE	1		
18	22	47625	ELBOW, OIL LEVEL GAUGE TUBE	1		
19		87353A 2	GAUGE, OIL LEVEL (DIPSTICK)	1		
20	24	32817	SPRING	1		
21	54	71982 2	CLIP, OIL LEVEL TUBE	1		