



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		44187	1 HOUSING, FLYWHEEL	1		
2	19	12304	PLUG, TIMING WINDOW	1		
3	10	37612	SCREW, FLYWHEEL HOUSING	3		
3	10	47688	SCREW, FLYWHEEL HOUSING	2		
4	13	35048	LOCKWASHER, FLYWHEEL HOU	7	SCREW AND STUD	
5	12	20553	WASHER, FLYWHEEL HOUSING	5		
5	12	20572	WASHER, FLYWHEEL HOUSING	1	(FOR SLOT)	
6	54	62494	CLAMP, FLYWHEEL HOUSING SC	1		
7	16	64066	STUD, FLYWHEEL HOUSING (2-1	2		
8	11	32219	NUT, FLYWHEEL HOUSING STUI	2		
9	84	62826A	7 WIRE ASSEMBLY, GROUND	1		
10		17917	BRACKET, SHIFT	1		
11	10	28668	SCREW, SHIFT BRACKET	2		
12	11	20586	NUT, SHIFT STUD	1		
13	12	39143	WASHER, SHIFT STUD	1		
14	23	53811	SPACER, SHIFT STUD	2		
15	16	63335	STUD, SHIFT	1		
16	12	21631	WASHER, SHIFT STUD	2		
17	23	31866	SPACER, SHIFT STUD	1		
18	11	20361	NUT, SHIFT STUD	1		