

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	57	807755	4 BELT-Serpentine	1		
2	10	849377	SCREW (.312-24 x .750)	4		
3	12	70132	WASHER	4		
4		849047T	PULLEY (Blue)	1		
5	10	811574	SCREW (.375-16 x 1.750)	4		5
6		850454	1 PUMP ASSEMBLY-Circulating	1		5
7	27	49110	GASKET	2		2
8	22	61162	PLUG (.500)	1		5
9	27	818188	1 GASKET	2		2,5
10		816073	SHIELD-Heat	1		5
11		807211	VALVE-Relief	1	(Oil By Pass - 30 PSI)	5
12	27	850456	GASKET-Front Cover	1		2,5
13		850459	COVER ASSEMBLY-Front	1		5
14	26	821947	1 SEAL-Oil	1		2
15	10	850455	SCREW	10		5
16		850460	BALANCER	1		5
17		849045T	PULLEY (Blue)	1		5
18	12	856774	WASHER	3		5
19	10	86517	SCREW (.375-16 x 1.250)	3		5
20	12	841390	WASHER	1		
21	12	822350	WASHER	1		5
22	10	48490	SCREW (.500-20 x 2.50)	1		5
-	27	842182A	1 GASKET/SEAL SET-Engine Overh	1	(See Gasket/Seal Set-Engine Ove	

