



- 25
VALVE KIT-RELIEF
(UP PRESSURE)
- 26
VALVE KIT-RELIEF
(DOWN PRESSURE)
- 27
VALVE KIT
(THERMAL RELIEF)
- 28
REPAIR KIT
(OVERHAUL)

2546

| Parts List | | | | | | |
|------------|-------|-----------|----------------------------------|-----|------------------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 14336A31 | PUMP/MOTOR ASSEMBLY | 1 | (Design III - Etch Manufacturing N | 1 |
| 2 | | 891736T | MOTOR ASSEMBLY (Complete) | 1 | (Design II - Etch Manufacturing N | |
| 3 | | 891737 | BRUSH KIT | 1 | | |
| 4 | | 891738 | HOLDER ASSEMBLY-Brushes | 1 | | |
| 5 | 10 | 891739 | SCREW-Brush Holder | 2 | | |
| 6 | 25 | 891740 | O RING | 1 | | |
| 7 | | NSS | END CAP ASSEMBLY | 1 | | |
| 8 | 10 | 891741 | SCREW | 4 | | |
| 9 | | NSS | COVER ASSEMBLY (With Bear | 1 | | |
| 10 | | NSS | FIELD AND FRAME ASSEMBL | 1 | | |
| 11 | | NSS | WASHER-Thrust | 2 | | |
| 12 | | NSS | ARMATURE | 1 | | |
| 13 | | 892608 | CIRCUIT BOARD-RFI Filter | 1 | | 1 |
| 14 | | NSS | SCREW | 2 | | |
| 15 | 10 | 823444 | SCREW | 2 | | |
| 16 | | 808728T | ADAPTOR ASSEMBLY | 1 | | |
| 17 | | 803852 | COUPLING | 1 | | |
| 18 | 25 | 89498 | O RING (Motor End) | 1 | | |
| 19 | | 18529 | PUMP ASSEMBLY (With Screw | 1 | | |
| 20 | 35 | 89496 | FILTER | 2 | | |
| 21 | 25 | 17645 | O RING (Reservoir End) | 1 | | |
| 22 | | 883166A | RESERVOIR KIT | 1 | (With Filters-Ref 20 And O Ring-Rc | |
| 23 | 36 | 861597 | CAP-Oil Reservoir | 1 | (Standard) | |
| 23 | 36 | 865448A01 | CAP-Oil Reservoir | OPT | (Rough Water Application) | 1 |
| 24 | 10 | 883167 | SCREW (#8-32) | 4 | | |
| 25 | | 812498A | VALVE KIT-Relief (Up Pressure) | 1 | | |
| 26 | | 812499A | VALVE KIT-Relief (Down Pressure) | 1 | | |
| 27 | | 95353A | VALVE KIT (Thermal Relief) | 1 | | |
| 28 | | 18545A | REPAIR KIT (Overhaul) | 1 | | |