



25  
 VALVE KIT-RELIEF  
 (UP PRESSURE)

26  
 VALVE KIT-RELIEF  
 (DOWN PRESSURE)

27  
 VALVE KIT  
 (THERMAL RELIEF)

28  
 REPAIR KIT  
 (OVERHAUL)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14336A31	PUMP/MOTOR ASSEMBLY	1	(Design III - Etch Manufacturing N	1
2		891736T	MOTOR ASSEMBLY (Complete)	1	(Design II - Etch Manufacturing N	
3		891737	BRUSH KIT	1		
4		891738	HOLDER ASSEMBLY-Brushes	1		
5	10	891739	SCREW-Brush Holder	2		
6	25	891740	O RING	1		
7		NSS	END CAP ASSEMBLY	1		
8	10	891741	SCREW	4		
9		NSS	COVER ASSEMBLY (With Bear	1		
10		NSS	FIELD AND FRAME ASSEMBL	1		
11		NSS	WASHER-Thrust	2		
12		NSS	ARMATURE	1		
13		892608	CIRCUIT BOARD-RFI Filter	1		1
14		NSS	SCREW	2		
15	10	823444	SCREW	2		
16		808728T	ADAPTOR ASSEMBLY	1		
17		803852	COUPLING	1		
18	25	89498	O RING (Motor End)	1		
19		18529	PUMP ASSEMBLY (With Screw	1		
20	35	89496	FILTER	2		
21	25	17645	O RING (Reservoir End)	1		
22		883166A	RESERVOIR KIT	1	(With Filters-Ref 20 And O Ring-Rc	
23	36	861597	CAP-Oil Reservoir	1	(Standard)	
23	36	865448A01	CAP-Oil Reservoir	OPT	(Rough Water Application)	1
24	10	883167	SCREW (#8-32)	4		
25		812498A	VALVE KIT-Relief (Up Pressure)	1		
26		812499A	VALVE KIT-Relief (Down Pressure)	1		
27		95353A	VALVE KIT (Thermal Relief)	1		
28		18545A	REPAIR KIT (Overhaul)	1		