

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	57	807755	BELT-Serpentine	4	
2	10	849377	SCREW (.312-24 x .750)	4	
3	12	70132	WASHER	4	
4		849047T	PULLEY (Blue)	1	
5	10	811574	SCREW (.375-16 x 1.750)	4	5
6		850454	PUMP ASSEMBLY-Circulating	1	5
7	27	49110	GASKET	2	2
8	22	61162	PLUG (.500)	1	5
9	27	818188	GASKET	2	2,5
10		816073	SHIELD-Heat	1	5
11		807211	VALVE-Relief	1	(Oil By Pass - 30 PSI) 5
12	27	850456	GASKET-Front Cover	1	2,5
13		850459	COVER ASSEMBLY-Front	1	5
14	26	821947	SEAL-Oil	1	2
15	10	850455	SCREW	10	5
16		850460	BALANCER	1	5
17		849045T	PULLEY (Blue)	1	5
18	12	856774	WASHER	3	5
19	10	86517	SCREW (.375-16 x 1.250)	3	5
20	12	841390	WASHER	1	
21	12	822350	WASHER	1	5
22	10	48490	SCREW (.500-20 x 2.50)	1	5
-	27	842182A	GASKET/SEAL SET-Engine Overh	1	(See Gasket/Seal Set-Engine Ove

