



TERMOSTAT HOUSING

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		847704 2	HOUSING-Thermostat	1		1
2	22	36373	PLUG-Pipe (.375-18)	1		
3	16	847742	STUD	1		
4	30	98475	BALL (Nylon)	2		
5	24	75533	SPRING	2		
6	11	29488	NUT (#10-32)	2		
7	27	818364	GASKET-Thermostat Cover	1		2
8		59137 1	THERMOSTAT	1		
9		849875 1	COVER-Thermostat	1		
10	12	37828	WASHER	3		
11	10	30206	SCREW (.375-16 x 1.00)	3		
12	12	37828	WASHER	3		
13	10	65210	SCREW (.375-16 x 1.00)	3		
14	25	20826	O RING	1	(Thermostat Housing To Intake Manifold)	2
15	32	53461 70	HOSE (48.00 Inches)	1	(Drive To Sea Pump) (Six Drive)	
15	32	17435 65	HOSE (38.00 Inches)	1	(Drive To Sea Pump) (Bravo Mode)	
15	32	13556A 1	HOSE KIT (10.00 Feet)	1	(Drive To Sea Pump) (Driveline Motor)	
16	54	18076 6	CLAMP	10		
17	32	849935	HOSE-Molded	1	(Sea Pump To Fuel Cooler)	
18	32	844881	HOSE-Molded	1	(Fuel Cooler To Oil Cooler)	
19	32	848956	HOSE-Molded	1	(Oil Cooler To Tube)	
20	22	13177	TUBE-Hose Attachment	1	(Non Power Steering)	
21	32	844475	HOSE-Molded	1	(Tube To Thermostat Housing)	
22	32	842412A 1	HOSE ASSEMBLY	1	(Thermostat To Circulating Pump)	
23	22	860088	BUSHING	1		
24	22	806608A 1	PLUG KIT	1		
25	25	32509	O RING	1		
26	22	37682	ELBOW (45 Degree)	1		
27	54	18076 8	CLAMP	2		
28	54	18076 4	CLAMP	8		
29	32	849942	HOSE ASSEMBLY	1	(Port) (Thermostat Cover To Exhaust)	
30	32	849943	HOSE ASSEMBLY	1	(Starboard) (Thermostat Cover To Exhaust)	
31	32	849940	HOSE ASSEMBLY	1	(Port) (Thermostat Tee To Exhaust)	
31	32	849941	HOSE ASSEMBLY	1	(Starboard) (Thermostat Tee To Exhaust)	
-	27	842182A 1	GASKET/SEAL SET-Engine Overhaul	1	(See Gasket/Seal Set-Engine Overhaul)	