



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A 7	HOUSING ASSEMBLY-Flywheel	1		
2		88791T	Mount-Rubber	2		
3	23	99322	SPACER-Rubber Mount	2		
4	10	32132	SCREW (.375-16 x 1.750)	1		
5	16	64066	STUD (2.750 Inches)	2	(Flywheel Housing Attaching)	
6	11	32219	NUT (.375-16)	2	(Flywheel Housing Attaching Stud)	
7	13	35048	LOCKWASHER (.375)	2	(Flywheel Housing Screw)	
8	12	74759	WASHER-Special (.375)	1	(Flywheel Housing Screw)	
9		807260A 2	COVER KIT-Flywheel	1		
10	10	45561 1	SCREW (.250-20 x 1.120)	2		
11	84	62826A 6	CABLE ASSEMBLY (Black)	2		
12	54	62494	CLIP-Water Hose	1		
13	12	856774	WASHER	6		
14	12	846673	WASHER	2		
15	10	35047	SCREW	1	(.375-16 x 1.250)	
15	10	58642	SCREW	2	(.375-16 x 1.500)	