



- | | | | |
|-----------------------------------|-------------------------------------|-------------------------------|--------------------------|
| 23 | 24 | 25 | 26 |
| VALVE KIT-RELIEF (UP PRESSURE) | VALVE KIT-RELIEF (DOWN PRESSURE) | VALVE KIT (THERMAL RELIEF) | REPAIR KIT (OVERHAUL) |

| Parts List | | | | | | |
|------------|-------|-----------|----------------------------------|-----|---------------------------------------------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 14336A 8 | PUMP/MOTOR ASSEMBLY | 1 | (Bottom Mounted Reservoir) (Design I - Small Manufacturing De | |
| 2 | | 17649T | MOTOR ASSEMBLY (Complete) | 1 | (Design I - Small Manufacturing De | |
| 3 | | 17631A 1 | BRUSH KIT | 1 | | |
| 4 | | 17633 | HOLDER KIT-Brush | 1 | | |
| 5 | 10 | 17621 | SCREW | 2 | | |
| 6 | 25 | 17625 | O RING | 1 | | |
| 7 | | 17632T | END CAP ASSEMBLY (With Be | 1 | | |
| 8 | 10 | 17626 | SCREW | 4 | | |
| 9 | | 17622 | COVER ASSEMBLY (With Bear | 1 | | |
| 10 | | 17624 | FIELD AND FRAME ASSEMBL | 1 | | |
| 11 | 12 | 17653 | WASHER-Thrust | 2 | | |
| 12 | | 17623 | ARMATURE | 1 | | |
| 13 | 10 | 823444 | SCREW | 2 | | |
| 14 | | 808728T | ADAPTOR ASSEMBLY | 1 | | |
| 15 | | 803852 | COUPLING | 1 | | |
| 16 | 25 | 89498 | O RING (Motor End) | 1 | | |
| 17 | | 18529 | PUMP ASSEMBLY (With Screw | 1 | | |
| 18 | 35 | 89496 | FILTER | 2 | | |
| 19 | 25 | 17645 | O RING (Reservoir End) | 1 | | |
| 20 | | 18525A 1 | RESERVOIR KIT | 1 | (Bottom Mounted) (With O Ring - F | |
| 21 | 36 | 18526 | CAP-Oil Reservoir | 1 | (Standard) | |
| 21 | 36 | 865448A01 | CAP-Oil Reservoir | OPT | (Rough Water Application) | 1 |
| 22 | 10 | 18527 | SCREW | 1 | (With O Ring And Spacer) | |
| 23 | | 812498A 1 | VALVE KIT-Relief (Up Pressure) | 1 | | |
| 24 | | 812499A 1 | VALVE KIT-Relief (Down Pressure) | 1 | | |
| 25 | | 95353A 1 | VALVE KIT (Thermal Relief) | 1 | | |
| 26 | | 18545A 1 | REPAIR KIT (Overhaul) | 1 | | |