



2506

Parts List					
Ref	Class	Part	Description	Qty	Footnote
0	1626	2550A 3	GEAR HOUSING-COMPLETE	1	
1	1626	2550A 1	GEAR HOUSING (BASIC)	1	
30		36288	SHIFT CAM	1	
31		38441	CAM FOLLOWER	1	
32		20843	SLIDE-Cross Pin	1	
33	24	20254	SPRING-Cam Follower	1	
34	15	38374A 1	SHIM SET-Bearing Cup to Gear F	AR	
0	43	38355A 1	FORWARD GEAR ASSEMBLY	1	
35	43	38355	FORWARD GEAR ASSEMBLY	1	
36	31	20249	ROLLER BEARING	1	
37	31	38356A 1	TAPERED ROLLER BEARING	1	
38		NSS	CUP	1	
39	52	38128	CLUTCH	1	
40	17	38113	CROSS PIN-Clutch to Prop Shaft	1	
41	24	38114	SPRING-Cross Pin	1	
42	44	38127	PROPELLER SHAFT	1	
0	43	38129A 2	REVERSE GEAR ASSEMBLY	1	
43	43	38129	REVERSE GEAR	1	
44	12	32004	THRUST WASHER-Bearing Ca	1	
45	30	20839	BALL BEARING	1	
46	15	20927A 1	SHIM SET-Thrust Washer to Gear	AR	
47	25	31986	O RING-Bearing Carrier	1	
48		38130A 1	BEARING CARRIER ASSEMBLY	1	
49	31	20249	ROLLER BEARING	1	
50	26	23300	OIL SEAL	1	
51	26	23517	OIL SEAL	1	
52	28	30281	KEY-Bearing Carrier	1	
53	12	31993	WASHER-Gear Housing Cover	1	
54		32014	COVER-Gear Housing	1	
55		38859A 1	THRUST HUB AND WASHER A	1	
56	12	31992	CUPPED WASHER	1	
57	12	32007	SPLINED WASHER-Prop Shaft	1	
58	11	31990	PROPELLER NUT	1	
59		31640A 1	TRIM TAB	1	
60	10	32470	SCREW-Trim tab to Gear Housing	1	
61	11	39433	NUT-Drive Shaft Housing to Gear F	1	
62	11	23161	NUT-Drive Shaft Housing to Gear F	1	
0	48	33774A 1	PROPELLER ASSEMBLY	1	(10 IN. PITCH)
0	48	38098A 1	PROPELLER ASSEMBLY	1	(11 IN. PITCH)
0	48	38094A 1	PROPELLER ASSEMBLY	1	(12 IN. PITCH)
0	48	38090A 1	PROPELLER ASSEMBLY	1	(13 IN. PITCH)