



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		38536	CHOKE SOLENOID	1		
2		30050	TERMINAL, CHOKE SOLENOID	1		
3		38530	BRACKET, MOUNTING - CHOKE	1		
4	10	33231	SCREW, MOUNTING BRACKET T	2		
5	13	20202	LOCKWASHER, MOUNTING BRA	2		
6	10	20705	SCREW, CHOKE SOLENOID TO	2		
7	11	35814	NUT, CHOKE SOLENOID SCREW	2		
8	10	24231	SCREW, CHOKE SOLENOID LEA	1		
9	11	20645	NUT, CHOKE SOLENOID LEAD SI	1		
10	23	32914	SLEEVE, CHOKE SOLENOID LEA	1		
11		27031A	PLUNGER AND LINK ASSEMBLY	1		
12	18	26953	COTTER PIN, LINK TO BELL CRA	1		
13		38572	BRACKET, MOUNTING - BELL CR	1		
14	10	20189	SCREW, MOUNTING BRACKET T	2		
15	13	26996	LOCKWASHER, MOUNTING BRA	2		
16		38519	, CHOKE	1		
17	16	30172	STUD, BELL BRANK TO MOUNTI	1		
18	23	33109	BUSHING BELL CRANK STUD	1		
19	12	30164	WASHER BELL CRANK STUD	2		
20	11	20110	NUT, BELL CRANK STUD	1		
21		38574	ROD CHOKE	1		
22		38573	SWIVEL, CHOKE ROD TO BELL C	1		
23	12	30164	WASHER, CHOKE ROD SWIVEL	1		
24	11	20110	NUT, CHOKE ROD SWIVEL TO BI	1		
25	11	20645	NUT, JAM - CHOKE ROD TO SWI	1		
26	11	20110	NUT, CHOKE ROD TO SWIVEL	1		