



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		37135	FUEL PUMP ASSEMBLY	1		
2		37136	DIAPHRAGM, FUEL PUMP	1		
3	10	37144	SCREW, FUEL PUMP CLAMPIN	6		
4	12	37145	WASHER, FUEL PUMP CLAMP	6		
5	25	37143	"O" RING, FUEL PUMP FILTER	1		
6		37142	FILTER, FUEL PUMP	1		
7	23	37150	SLEEVE, FUEL PUMP FILTER	1		
8		37149	CAP, FUEL PUMP FILTER SLEE	1		
9		37146	BALE, FUEL PUMP	1		
10	10	37147	SCREW, FUEL PUMP BALE	1		
11	11	37148	NUT, FUEL PUMP BALE SCREW	1		
12	27	37137	GASKET, FUEL PUMP	2	(Part of 27-37073A1)	
13		37138	PLATE, FUEL PUMP MOUNTING	1		
14	16	37112	STUD, FUEL PUMP TO CYLINDER	1		
15	10	37139	SCREW, FUEL PUMP TO CYLIND	1		
16	13	37141	LOCKWASHER, FUEL PUMP SCR	2		
17	11	37140	NUT, FUEL PUMP STUD	1		
18	32	38523	FUEL LINE, INLET-FUEL TANK TO	1		
19	32	38529	FUEL LINE, FUEL PUMP TO REAR	1		
20	22	28624	TEE, FUEL LINES TO REAR CARB	1		
21	1342	2564	CARBURETOR ASSEMBLY, REAR	1		
22	27	38531	GASKET, CARBURETOR MOUNT	2	(Part of 27-37097A1)	
23	10	21339	SCREW, REAR CARBURETOR TO	1		
24	10	20639	SCREW, CARBURETOR INTAKE	3		
25	11	20102	NUT, CARBURETOR SCREW	4		
26		38508A	ADAPTOR ASSEMBLY, FLAME AR	1		
27		38509	ADAPTOR, FLAME ARRESTOR-FI	1		
28	27	38564	GASKET, FLAME ARRESTOR AD	2	(Part of 27-37097A1)	
29	10	20646	SCREW, FLAME ARRESTOR ADA	4		
30	13	26996	LOCKWASHER, FLAME ARREST	4		
31		38567	ELEMENT, FLAME ARRESTOR	2		
32		38568	PLATE, FLAME ARRESTOR ELEM	2		
33	10	29794	SCREW, FLAME ARRESTOR PLA	4		
34	13	26996	LOCKWASHER, FLAME ARREST	4		
35	1342	2565	CARBURETOR ASSEMBLY, FROF	1		
36	32	38527	FUEL LINE, REAR CARBURETOR	1		
37		38672	HOOD, FLAME ARRESTOR	1		
38	10	29794	SCREW, FLAME ARRESTOR HOC	4		
39	13	26996	LOCKWASHER, FLAME ARREST	4		
40	12	26013	WASHER, FLAME ARRESTOR HC	4		
41	19	22862	BUTTON PLUG, FLAME ARREST	2		