



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3312	821030A15	CARBURETOR (REAR) (BLUE)	1		
1	3312	821030A16	CARBURETOR (FRONT) (BLUE)	1		
2		818892	SPACER-Carburetor Base	2		4
3		818974A 1	LINKAGE ASSEMBLY-Throttle	1		1
4		818975	LINK-Connecting	2		
5		818978	LINK-Connecting	1		
6	10	818980	SCREW	1		
7		818979	BELLCRANK-Lower	1		
8	11	35045	NUT (.250-28)	6		
9	10	821282	SCREW (.250-28 x .750)	4		
10	10	92702	SCREW (.250-28 x .875)-Link Arm	2		
11	23	818894	BUSHING-Carburetor Lever	2		
12	12	28426	WASHER	2		
13	11	35045	NUT (.250-28)	1		
14	24	821001	SPRING-Throttle Return	1		
15	11	21825	NUT (.250-28)	1		
16	16	98851	STUD (.250-28 x 1.500)	1		
17	12	29245	WASHER	2		
18	11	56374	NUT (.250-20)	1		
19		818995	BRACKET-Throttle Cable	1		
20	11	35045	NUT (.250-28)	1		
21	11	25168	NUT (.250-28) (THIN)	1		
21	11	21825	NUT (.250-28) (THICK)	1		
22	16	72809	STUD (.250-28 x 1.625)	1		
23	12	21631	WASHER	2		
24	23	31866	SPACER	1		
25	11	56374	NUT (.250-20)	1		
26	32	821120A 1	RAIL ASSEMBLY-Fuel	1		
27	22	817395	FITTING (45 Deg)	1		
28	22	73379	PLUG	1		
29	32	821121	LINE-Fuel-Carb To Rail (Short)	2		
30	32	821122	LINE-Fuel-Carb To Rail (Long-Front)	1		
31	32	821123	LINE-Fuel-Carb To Rail (Long-Rear)	1		
32	54	847630 12	CLAMP-Hose	4		
33	32	821284 33	HOSE (14.00 In.)-Breather	2	(SERIAL # 0D456489 THRU 0F6	
33	32	821284A 8	HOSE ASSEMBLY (16.00 In.)	2	(SERIAL # 0F615828 THRU 0F8	
34	16	30667	STUD (.250-28 x 3.125)-Flame Arre	2		
35		818755	ARRESTOR-Flame (FRONT)	1	(SERIAL # 0D456489 THRU 0F6	
35		818756	ARRESTOR-Flame (REAR)	1	(SERIAL # 0D456489 THRU 0F6	
35		848623	ARRESTOR-Flame (FRONT)	1	(SERIAL # 0F615828 THRU 0F8	
35		848624	ARRESTOR-Flame (REAR)	1	(SERIAL # 0F615828 THRU 0F8	