



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		847704A 1	HOUSING ASSEMBLY-Thermostat	1		
2	22	36373	PLUG-Pipe (.375-18)	1		
3	16	847742	STUD-By Pass Valve	1		
4	30	98475	BALL-Nylon	2		
5	24	75533	SPRING	2		
6	11	29488	NUT (#10-32)	2		
7		59137 1	THERMOSTAT	1		
8	10	30206	SCREW (.375-16 x 1.00)-Cover To	2		
9	12	37828	WASHER	2		
10	32	847707A 6	HOSE ASSEMBLY (25.00 In.) (STA	1	Housing To Pipe	
11	32	847707A 3	HOSE ASSEMBLY (18.00 In.) (PDF	1	Housing To Pipe	
12	32	818361	HOSE-Tube To Thermostat Housin	1		
13	54	18076 6	CLAMP	10		
14	32	822525	HOSE-Thermostat Housing To Purr	1		
15	54	18076 8	CLAMP	2		
16	32	17435 65	HOSE-Pickup To Pump	1		
17	32	822036	HOSE-Pump To Transcooler	1		
18	32	816504	HOSE-Transcooler To Engine Cool	1		
19	32	12818	HOSE-Engine Cooler To Connector	1		
20	22	13177	TUBE-Connector	1		
21	32	847707A 2	HOSE ASSEMBLY (16.00 In.)-Cove	1	(STARBOARD)	
22	32	847707A 1	HOSE ASSEMBLY (12.00 In.)-Cove	1	(PORT)	
23	25	20826	O RING	1		4
24	12	20086	WASHER-Housing To Manifold	3		
25	10	34353	SCREW (.375-16 x 1.00)-Housing T	3		
26		847706 1	COVER-Thermostat (Painted)	1		
27	27	818364	GASKET-Thermostat	1		4
-	27	818188A91	GASKET SET-Engine Overhaul	1	(Ser. # 0D456489 Thru 0D45676E	
-	27	818188A96	GASKET SET-Engine Overhaul	1	(Ser. # 0D725676 Thru 0F877642	