



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A82	PUMP ASSEMBLY-Sea Water (Cor	1		
2	46	72774A89	BODY/IMPELLER KIT-Sea Water	1		
3	27	805215 1	GASKET-Cover to Outer Wear Pl	1		
4	27	94914	GASKET-Body to Wear Plate	2		
5	47	59362 1	IMPELLER	1		
6	25	94288	RING-Quad-Pump Housing	1		
7		821707 1	COVER-Sea Water Pump	1		
8	10	99347	SCREW (.312-18 x 4.500)	5		
9	12	20084	WASHER	10		
10		94916	WEAR PLATE-Outer	1		
11		94576	WEAR PLATE-Inner	1		
12	19	59504	PLUG-Impeller	1		
13		818367A 1	HOUSING ASSEMBLY-Sea Water	1		
14	26	90562	SEAL-Oil-Sea Water Pump Sha	2		
15		818366A 1	SHAFT ASSEMBLY	1		
16		818745A 1	SLIP RING KIT	1		
17	30	72961	BEARING-Ball-Sea Water Pump	2		
18	53	23720	RING-Retaining-Ball Bearing	1		
19	26	806930	SEAL-Oil-Sea Water Pump Sha	1		
20		818365T	PULLEY (BLACK)	1		
20		818365 2	PULLEY (BLUE)	1		
21	13	39107	LOCKWASHER (.312)	1		
22	11	21908	NUT (.312-18)	1		
23	10	79953A 2	SCREW PLUG ASSEMBLY	1		
24	12	19183	SEAL	1		
25		823185A 2	BRACKET KIT-Sea Water Pump	1		
26	10	91903	SCREW (.437-14 x 1.750)	3		
27	10	98261	SCREW (.375-16 x .750)	2		
28	13	35048	LOCKWASHER (.375)	2		
29	10	99204	SCREW (.437-14 x 1.00)	1		
30	43	818381 2	PINION STUD	1		
31		818380	BUSHING	1		1
32		818382	PULLEY	1		
33	11	817618	NUT	1		
34	57	69143T	V BELT	1		
35	12	27025	WASHER	1		
36	12	45176	WASHER	4		
37		818379T	BRACKET-Idler	1		