



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	849142A	1 HARNESS ASSEMBLY-Wiring	1		
2		26079A	2 PLATE KIT	1		
3		15001	1 SCREW (#8-16 x .875)	4		
4		848734	1 BRACKET-Electrical Components	1		
5	88	11178	1 BREAKER-Circuit (50 AMP)	1		
6	13	26396	2 LOCKWASHER (#10)	2		
7	11	68219	2 NUT (#10-32)	2		
8	10	45862	2 SCREW (#10-32 x .875)	2		
9	11	61356	2 NUT (#10-32)	2		
10	89	818999A	2 SOLENOID ASSEMBLY-Starter	1		
11	25	818967	2 GROMMET	2		
12	23	818968	2 BUSHING	2		
13	12	29245	2 WASHER	2		
14	13	26392	2 LOCKWASHER (.250)	2		
15	10	76630	2 SCREW (.250-20 x 1.00)	2		
16	13	26395	2 LOCKWASHER (#8)	2		
17	11	26419	2 NUT (#8-32)	2		
18	13	26392	2 LOCKWASHER (.250)	2		
19	11	94330	2 NUT (.250-20)	2		
20		13611	1 SENDER ASSEMBLY-Oil Temporal	1		
21	13	26396	3 LOCKWASHER (#10)	3		
22	11	45076	3 NUT (#10-32)	3		
23	22	64013	2 REDUCER-Engine Block	2		
24		97257A	1 SENDER ASSEMBLY-Water Temp	1	Thermostat Housing	
24		49734A	1 SENDER ASSEMBLY-Water Temp	OPT	(DUAL)	4
25		815425	1 SENDER ASSEMBLY-Oil Pressure	1		
25		37293	1 SENDER ASSEMBLY-Oil Pressure	OPT	(DUAL)	4
26	22	29085	1 FITTING (45 Deg.)	1		
27		807763T	1 BRACKET-Module Mounting	1		
28	10	806827	6 SCREW (#8-32 x .375)	6		
29		848824	1 MODULE-Ignition	1		
30		805443T	1 MODULE ASSEMBLY-Spark Contr	1		
31		805544T	1 SENSOR ASSEMBLY-Knock	1		
32	12	45176	3 WASHER	3		
33	10	825427	3 SCREW-Bracket Mount (.437-14 x	3		
34	54	848183	1 J CLIP-Electrical Harness	1		
35	54	78945	1 J CLIP-Electrical Harness To Front	1		